## The Solarbotics Arduino/ Freeduino Enclosure

Clever eh? Took us much less time to come up with the name than the design time to get this *juuust* right. Feel free to cut your own S.A.F.E. with this design file!

Parts required:

3mm Acrylic

8 x #4-40 x 3/8 bolts

8 x #4-40 Hex Nuts

4 x #4 Nylon spacers

4 x Little Rubber Feet (aka: LRF)

SKU: 60100 http://www.solarbotics.com/products/60100









## For easy assembly, follow these steps:

- 1) Place the spacers on the Baseplate then screw the Arduino / Freeduino to it with 4 of the #4-40 bolts.
- 2) Put the power switch tab on the power switch (Freeduino only).
- 3) Slide the nuts into the T-Slots, and screw down the sides, and then the top.
  - Note: If it's hard to insert the nuts, try putting them in from the *other side*. Lasering makes one side a bit more open than the other.

- 4) Nest together the 4 pieces that make up the walls of the enclosure (not on the baseplate). Make sure the faceplate is right-side-up & out.
- 5) While tilting the 4-piece assembly, slip the faceplate onto the Arduino/Freeduino & power switch, and then rotate the assembly down flat into the slots on the baseplate. The just thread the remaining screws into the nuts and now the enclosure is finished....well not guite...put a lid on it! No, we're not being rude, just screw down the top plate on the SAFE and it is now complete.




Assemble the 4 walls, and install the set by slipping the faceplate over the USB jack and power switch first.







3740D - 11A Street NE, Suite 101

Solarbotics Ltd.






LCD Top plate with panel mount button cutouts



"Tall" side plate so you can nest a 5-cell AA battery pack underneath



 $\Theta$ 

Standard front faceplate with Arduino / Freeduino knock-outs

Back plate. The cutouts on the corners are wire passageways

Netduino Plus faceplate (doesn't fit standard Netduino)