
## PLUSH CAT TEMPLATE

Kit: SparkFun.com/eSewingProtoSnap







Stitch all hardware onto fabric and test before stitching sides together.

Stitch 1/4" seam to join pieces, leave opening at bottom.

Turn inside out and stitch ears closed.

Stuff and finish bottom seam.


Add fabric covers to ears to hide battery holder and switch, stitch bottom edges, leave side open for battery access and cut hole for switch.



## PLUSH CAT TEMPLATE

Kit: SparkFun.com/eSewingProtoSnap







For use on printable fabric or as templates

ADJUST PRINT MARGINS TO ALLOW FULL IMAGE TO PRINT