

BME280 Breakout

MODES:

I2C:


Leave the copper-connected jumpers SJ1-SJ2 as default, use SJ3 to set the I2C address.

SPI 4-WIRE:

Jumpers SJ1-SJ3 can be opened to remove 4.7k load on the SPI lines but is not necessary.


SPI 3-WIRE:

SJ3 must be opened.



Ports:

(Use only 1)



open hardware

Released under the Creative Commons
Attribution Share-Alike 4.0 License
<https://creativecommons.org/licenses/by-sa/4.0/>



TITLE: SparkFun_BME280_Breakout_v10

Design by: Marshall Taylor

REV:
V10

Date: 10/22/2015 12:23 PM

Sheet: 1/1